



USA Measurements

"We Outmeasure the Competition"

Operation manual

"The Lifter" US-LC Crane scale

V5.02

1. Overview

USA Measurements series US-LC electronic series hanging scales. Designed with a high-precision alloy steel load cell. Developed specifically for overhead hanging applications. Built with an A/D converter and large display. Our US-LC features a 1.2-inch (digit height) ultra-bright LED display for easy reading from a far distance. The US-LC features a unique anti-vibration and short settling time.

The US-LC has functions for accumulation, low power consumption, and a rechargeable battery. Our scale is designed with power saving function to auto shut off. This helps with saving battery life. The LED display can work continuously on the rechargeable battery for up to 30 hours. The battery also features an over-charge protection to avoid damage to the battery. Included with our US-LC series crane scale is a 1 year manufacture warranty on parts, labor, and electronics.

- ◎ Operating temperature range: $-10\text{ }^{\circ}\text{C} \sim +40\text{ }^{\circ}\text{C}$;
- ◎ A / D conversion speed: 80 times / sec;
- ◎ Relative temperature: <90% RH;
- ◎ Sensor Supply Voltage: 5V;
- ◎ Accuracy: III; ◎ zero range: <10% FS;
- ◎ Peeled range: 10% of the FS-100 FS;
- ◎ wireless remote control the use of distance $\leq 15\text{ m}$;
- ◎ Wireless frequency: 433MHZ

2. Turning On the Scale: ON/OFF

1. When the scale is turned off. Press the [tare, ON / OFF] key to turn on, it will display the software version number: [Uer5.2] After that the scale will start its sequence count down from [999999] to [000000]. This is the self-test. After that the count down the scale will show zero: [0] and be ready for use.

2, panel buttons:

The button: [tare, ON / OFF] key; other button: [Query] key.

3, while the power, press and hold the [tare, ON / OFF] key, five seconds later the battery power: [Pbt85] Then release it, automatically cut off power, or delay to Paper process, once again press [tare, ON / OFF] key will cut off the power. Or press [B]+[A]key together by remote controller, it will cut off the power.

★ Note: Pbt85 the battery power for 85%;

3. Tare

1, instant tare: the state of light goes out, place heavy objects lifted until the weighing stability, press [tare, ON / OFF] key or [C] by remote controller.

★ Note: weighing stability, [stability] indicator light.

2, the delay tare: Press and hold [tare, ON / OFF] key 3 seconds after the display: [TArE-9] , then release it, it will display the value of minus one per second speed display [TarE-x] At this point, to lift heavy objects. When the display [TarE-0] , peeled automatically. If the weighing is also not stable, the display [UUUUU] ,

waiting for the weighing stability automatically peeled, the displayed value to zero, and [tare] indicator is lit.

4. Peak Hold

Press the remote controller B key, the display value is maintained, and then press the B key to be lifted.

5. Cumulative

Press [Query] button for 3 seconds, display [AUt-0].

Press[B] key by remote control ,display [AUt-1], Press [Query] button to confirm, system automatic opening function cumulative. ("AUt-0" close cumulative function, "AUt-1" open cumulative function).

Note: Automatically accumulated, each weighing finish, showing value to zero, the display weight automatically accumulated, it will close automatically function after shutting down every time.

6. Query

The function can query the accumulated weight and overload record "DAE-1": representing the latest 10 weighing data query

"DAE-2": represents the cumulative weight query

"DAE-3": query overload record

Short press [Query] button, display [DAE-0], enter the query function, press the [B] key by remote controller and modify [DAE-1], press [A] by remote controller to confirm to enter the last 10 weighing data query. Press the [B] key to read data.

Press the [A] button to return "DAE-1" state, press [B] and modify [DAE-2]. Press [A] key to confirm to enter the query cumulative weight and cumulative number of times; at this time it display [C XXX], press the [B] button to read query data,

For example: 800kg weight is continuous weighing 32 times, the total weight is 25600kg, hanging display:

"C 32", "H0002", "L5600"

Note: C is the total number of times, H is the high 4 digits of total amount, L is the low 4 digits of total amount.

Press the [A] button to return "DAE-2" state, press the [B] key and modify [DAE-3].

Press [A] button to confirm to enter the overload record query, it display overload of the times. Such as hanging without overload record, is shown as 0.

Press [A] to return to the "DAE-3" state, press the [B] key to modify the [DAE-0], and then press the [A] to confirm and return the weighing state.

Remote control key instructions

A: Query key / Number reduce 1

B: Hold key / Cursor right

C: Tare key / Number add 1

D: Function / Confirmation

B+A: Shutdown key

Calibration steps

Step	Operator	Display	Notice
1	Press [D]	[P0000]	Input password
2	Press [B] right Press [C]or[A] modify Press [D] confirm	[P8888]	Move the cursor, and then select the number, enter the correct password, Enter parameter settings
3	Press [C]or[A] modify Press [D] confirm	[E 001]	Set the division: 1, 2, 5, 10, 20, 50, 100
4	Press [C]or[A] modify Press [D] confirm	[DC 0]	Set the point :0, 1, 2, 3
5	Delay 2 seconds	[-CAP-]	Set the maximum range
6	Press [B] right Press [C]or[A] modify Press [D] confirm	[05000]	Set the maximum range, weighing process, more than this range, the system will automatically alarm.
7	Press [D] confirm	[ZEro]	In the calibration process, the zero operation, without load (press [B] to skip the zero operation)
8	Press [D] confirm	[SPAN]	Enter to Full scale calibration
9	Press [B] right Press [C]or[A] modify Press [D] confirm	[04000]	The sensor loads the weight, moves the cursor, and sets the current data to the actual load.
10	Press [B] right Press [C]or[A] modify Press [D] confirm	[01234]	The display coefficient.
11			Calibration end, return the weighing interface.

Parameter setting

Step	Operator	Display	Notice
1	Press [D]	[P 0000]	Input password
2	Press [B] right Press [C]or[A] modify Press [D] confirm	[P 9999]	Move the cursor, and then select the number, enter the correct password, Enter parameter settings
3	Press [C]or[A] modify Press [D] confirm	[LD 1d]	Zero tracking settings: 1d , 2d , 3d , 4d , 5d
4	Press [C]or[A] modify Press [D] confirm	[nb 0]	Filter set 0, 1, 2, 3, 4, 5 The number is bigger, the stable is faster too, but the reaction speed will slow down.
5	Press [C]or[A] modify Press [D] confirm	[S---1]	Power saving mode 0: off 1: open (when weight stability time of 5 minutes, LED display a prompt [-], when there is a change in weight, return to normal display state; when the weight stable time more than 30 minutes, automatically cut off the power supply)
6	Press [C]or[A] modify Press [D] confirm	[Pd 3]	Zero range, 0: Zero, 1: 2% , 2: 5% , 3: 10%, 4: 20%, 5: 50%
7	Press [C]or[A] modify Press [D] confirm	[L---4]	LED Brightness 0, 1, 2, 3, 4 The bigger the number, the higher the display.
8			Set end, return the weighing interface.

Error code

Err01 : Over maximum range

Err04: Zero when starting over on the set of zero range

L-v: Low battery power, need to charge in time

Err10: Other mistakes, please contact the seller

USA Measurements

“We Outmeasure the Competition”